

Setting HY DVR to MOTION Record

1. Log in to menu as "admin"
2. Select the "**Record Setup**" Icon (4th Icon down on left hand side)
3. Set "**Preset Config**" to "**Event Only**"
4. Select the "**Event Setup**" Icon (6th Icon down on the left hand side)
5. Select "**Per Channel Config**"
6. To enable motion detection for the selected channel set "**Motion Detect**" to "**ON**" You will need to do this for every camera channel by changing the "**Channel Select**" option.
7. Come out of the Menu by pressing "**ESC**" to save.

Notes:

- a. By default, the internal buzzer will sound each time there is motion. To disable this, set "**Internal Buzzer**" to "**OFF**" in the "**Event Setup**" screen.
- b. If required, you can mask out areas of the screen to stop motion being picked up by trees etc. To do this go to the "**Per Channel Config**" screen and select "**Detection Config**" and then go to "**Detected Area Setup**"